


How to setup a ZipWall® dust barrier


Step 1

Attach the head assembly to the pole and then slide the Non-Skid plate to remove it from the head.




Step 4

With the foot on the floor, press the spring-loaded head of the pole against the ceiling and then twist clockwise to lock.




Step 2

Clamp plastic sheeting between the two piece head assembly and slide the pegs into the keyhole slots to lock in.



Step 5

Ensure the plastic is not sagging between poles, and release then pull taut if required.




Step 3

Unlock the pole by twisting the inner pole, then extend up to ceiling with the plastic attached.



Step 6

To secure the sheeting at the base, lift each pole and pull the plastic under the foot to make a tight fit. You are now ready to go.



Email: info@zipwall.com.au
Or visit: zipwall.com.au

ZIPWALL[®]
The **zero dust** solution